Keys

The following keys are provided with the vehicle.

▶ Vehicles with power back door system

▶ Vehicles without power back door system

1 Master keys

2 Valet key

3 Key number plate

4 Flat key

When required to leave a key to the vehicle with a parking attendant

Lock the glove box as circumstances demand. (→ P. 241)
Carry the master key for your own use and leave the valet key only with the attendant.

Key number plate

Keep the plate in a safe place such as your wallet, not in the vehicle. In the event that a key is lost, a new key can be made at your Lexus dealer using the key number plate. (→P. 382)

NOTICE

To prevent key damage

- Do not subject the keys to strong shocks, expose them to high temperatures by placing them in direct sunlight, or get them wet.
- Do not expose the keys to electromagnetic materials or attach any material that blocks electromagnetic waves to the key surface.